



Wiring your Washer pump

The kit comes with a small pack of connectors. The plastic tee connector is for the motor connection. There are 2 gold spade connectors. Use these for the motor connection. Determine which side of the motor connection is the positive side. Look closely, it's indicated with a + next to the terminal. Determine how the plastic connector fits the motor and insert the brown wire into the correct slot with the gold spade crimped to the wire. Place the black wire in the other slot with the spade connector crimped on the black wire.

2 Speed Switch:

Run the brown wire included in the kit from the (W) terminal on the back of the switch to the positive side of the washer pump. Run the black ground wire from the negative side of the washer pump to a good ground.

Delay Switch:

Extend the brown wire from the back of the switch to the positive side of the washer pump. Run a ground wire from the negative side of the washer pump to a good ground. Pushing in on the knob will turn the pump on and squirt water